



Getting Started

To maintain the integrity of your deck structure during construction, begin removing boards from the outside (away from the building) and work towards the building.

Only remove 4 to 6 boards at a time and replace them with new decking. This will ensure you maintain the square spacing of the frame. You have two techniques for removing inline boards – Photos A & B.

Removing Decking

Slide the Deck Demon™ under the decking and pry up. For wide decking that you want to remove undamaged, pry up one side slowly and then slide the Deck Demon™ further under the board and pry up the other fasteners (C & D).

Pull Nails

From a standing position, wedge the catspaw around the fastener head and either roll the Deck Demon™ back and pull the nail or pry the nail out by pulling the Deck Demon™ to the side as shown in photo E.

New Deck Boards

When replacing the deck boards, first install a skirt board so the new decking will extend 3/4" of an inch off the frame. This will greatly decrease the chance that new fasteners will fall into existing holes (from previous fasteners).



Always wear proper eye, hand, and foot protection. Be sure to work from a safe and stable position.





Angel-GUARD Products, Inc.
Worcester, MA 01603
angelguardproducts.com
The Deck Demon™
Patented